Classic Humbucker Set Wiring
Standard wiring with dual voice switching.

FISHMAN *FLUENCE*™

Pot Controls:
1. Neck Volume
2. Neck Tone (Pull for Voice 2
3. Bridge Volume
4. Bridge Tone (Pull for HF Tilt)

9V Battery

(−)

(+)

Output Jack

Ring

Sleeve

Tip

Bridge Ground

Classic Neck Pickup

Classic Bridge Pickup

FISHMAN FLUENCE™

Classic Neck

FISHMAN FLUENCE™

Classic Bridge

CHBN Rev 0.0

CHBE Rev 0

COIL TAPS
CT   H

COIL TAPS
CT   H

25k **1**

25k **2**

.22uF

Pickup Selector
3-way Switch

Gibson® style 3-way switch shown.
Check your switch for compatibility.

Neck Pickup

Both

Bridge Pickup

Neck

Bridge

Out

25k **3**

25k **4**

.22uF